

Motorola Talkabout 2-way radios are intended for recreational (consumer) use only and is not intended for commercial/business use. As a separate product line, Motorola Solutions, Inc. offers an extensive range of commercial radio products designed specifically for business and public safety use.

For More Informatio

For further information, you may call Motorola Solutions, Inc. at 1-800-638-5119, e-mail us at support@giantintl.com or visit us on the

Safety and General Information

Important Information on Safe and Efficient Operation Read This Information Before Using Your Radio.

The information provided in this document supersedes the general safety information in user guides published prior to December 1, 2002.

Transmit and Receive Procedure

Your two-way radio contains a transmitter and a receiver. To control your exposure and ensure compliance with the general population/ uncontrolled environment exposure limits, always adhere to the following

- Transmit no more than 50% of the time.
- To receive calls, release the PTT button.
- To transmit (talk), press the Push to Talk (PTT) button.

Transmitting 50% of the time, or less, is important because the radio generates measurable RF energy exposure only when transmitting (in terms of measuring standards compliance).

Exposure to Radio Frequency Energy

Your Motorola two-way radio complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission, Code of Federal Regulations; 47CFR part 2 sub-part J.
- American National Standards Institute (ANSI)/Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992.
- Institute of Electrical and Electronics Engineers (IEEE) C95. 1-1999 Edition
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998. Health Canada - Safety Code 6; Limits of Human Exposure to
- Radiofrequency Electromagnetic Energy in the Frequency Range from 3 kHz to 300 GHz (2009)
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation—Human Exposure) Standard, 2003.
- ANATEL ANNEX to Resolution No. 303 of July 2, 2002.
- ANATEL ANNEX to Resolution No. 533 of September 10, 2009.

To ensure optimal radio performance and make sure human exposure to radio frequency electromagnetic energy is within the guidelines set forth in the above standards, always adhere to the following procedures.

Portable Radio Operation and EME Exposure

Antenna Care

Use only the supplied or an approved replacement antenna Unauthorized antennas, modifications, or attachments could damage the radio and may violate FCC regulations.

Do NOT hold the antenna when the radio is "IN USE." Holding the antenna affects its effective range.

Body-Worn Operation

To maintain compliances with FCC RF exposure guidelines if you wear a radio on your body when transmitting always place the radio in a Motorola-supplied or approved clip holder, holster, case or body harness for this product. Use of non-Motorola-approved accessories may exceed FCC RF exposure guidelines.

If you do not use one of the Motorola-supplied or approved body-worn accessories and are not using the radio held in the normal use position, ensure the radio and its antenna are at least 1 inch (2.5 cm) from your

If applicable, when using any data feature of the radio with or without an accessory cable, position the radio and its antenna at least one inch

Approved Audio Accessories

- 53724: Remote Speaker with Push-to-Talk Microphone
- 53725: Headset with Swivel Boom Microphone
- 53727: Earbud with Push-to-Talk Microphone
- 53728: Flexible Ear Receiver • 56320: Earpiece with Boom Microphone
- **Electromagnetic Interference/Compatibility**

Note: Nearly every electronic device is susceptible to electromagnetic

interference (EMI) if inadequately shielded, designed or otherwise configured for electromagnetic compatibility. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

- 1. This device may not cause harmful interference; and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

To avoid electromagnetic interference and/or compatibility conflicts, turn off your radio in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

When instructed to do so, turn off your radio when onboard an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions.

Medical Devices - Pacemakers

The Advanced Medical Technology Association recommends that a minimum separation of 6 inches (15 cm) be maintained between a handheld wireless radio and a pacemaker. These recommendations are consistent with the independent research by and recommendations of the U.S. Food and Drug Administration.

People with pacemakers should:

- ALWAYS keep the radio more than 6 inches (15 cm) from their pacemaker when the radio is turned ON
- · Not carry the radio in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for
- interference is taking place

Medical Devices - Hearing Aids

Some digital wireless radios may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives

Medical Devices - Other

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Safety and General Use While Driving

Check the laws and regulations regarding the use of radios in the area where you drive, and always obey them. If you do use your radio while driving, please:

- · Give full attention to driving and to the road.
- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

The use of a two-way radio while engaged in activities requiring concentration may cause distraction or otherwise impair your ability to safely participate in such activities. Always use technology safely.

Do not place a portable radio in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable radio is placed in the air bag deployment area and the air bag inflates, the radio may be propelled with great force and cause serious injury to occupants

Potentially Explosive Atmospheres

Turn off your radio prior to entering any area with a potentially explosive atmosphere. Only radio types that are especially qualified should be used in such areas as "Intrinsically Safe," Do not remove, install or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Note: The areas with notentially explosive atmospheres referred to above include fueling areas such as below decks on hoats, fuel or chemical transfer or storage facilities, areas where the air contains

chemicals or particles (such as grain, dust or metal powders) and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often—but not

Blasting Caps and Areas

To avoid possible interference with blasting operations, turn off your radio when you are near electrical blasting caps, in a blasting area, or in areas posted "Turn off two-way radios." Obey all signs and instructions.

Operational Cautions

Antennas

Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.

Batteries

All batteries can cause property damage and/or bodily injury such as burns if a conductive material—like iewelry, keys or beaded chains—touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse or other container with metal objects

Exercise care when removing NiMH or AA batteries. Do not use sharp or conductive tools to remove either of these batteries.

Battery Charger Safety Instructions: Save these Instruction

- 1. Do not expose the charger to rain or snow.
- 2. Do not operate or disassemble the charger if it has received a sharp blow, or has been dropped or damaged in any way
- 3. Never alter the AC cord or plug provided with the unit. If the plug will not fit the outlet, have the proper outlet installed by a qualified electrician. An improper condition can result in a risk of electric
- 4. To reduce the risk of damage to the cord or plug, pull the plug rather than the cord when disconnecting the charger from the AC receptacle.
- 5. To reduce the risk of electric shock, unplug the charger from the outlet before attempting any maintenance or cleaning
- 6. Use of an attachment not recommended or sold by Motorola may result in a risk of fire, electric shock or personal injury.
- 7. Make sure the cord is located so it will not be stepped on, tripped over or subjected to damage or stress.
- 8. An extension cord should not be used unless absolutely necessary. Use of an improper extension cord could result in a risk of a fire and/or electric shock. If an extension cord must be used, make sure
- . The pins on the plug of the extension cord are the same number, size and shape as those on the plug of the charger.
- The extension cord is properly wired and in good condition.
- . The extension cord size is 18 AWG for lengths up to 100 feet, and 16 AWG for lengths up to 150 feet.
- Turn the radio OFF immediately if there is any reason to suspect that 9. The supply cord of the AC adaptor cannot be replaced. If the cord is damaged, call customer service at 1-800-638-5119 or e-mail us at support@giantintl.com.

FCC Licensing Information

Your Motorola radio operate s on General Mobile Radio Service (GMRS) frequencies and is subject to the Rules and Regulations of the Federal Communications Commission (FCC). The FCC requires that all operators using GMRS frequencies obtain a radio license before operating their equipment. To obtain the FCC forms, please visit the FCC's Web site at wireless.fcc.gov/uls/index.htm?job=home to source form 605 and 159, which includes all the instructions you will need. If you wish to have the document faxed or mailed, or if you have

questions, please use the following contact information

Changes or modifications not expressly approved by Motorola may void the user's authority granted by the FCC to operate this radio and should not be made. To comply with FCC requirements, transmitter adjustments

For a fax: Contact the Fax-On-Demand system	For mail service: Call the FCC Forms Hotline	If you have questions about the FCC License: Call the FCC
1-202-418-0177	1-800-418-FORM (3676)	1-888-CALL-FCC (225-5322)

should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization epresentative of the user of those services. Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the FCC equipment authorization for this radio could violate FCC rules.

Note: Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be prohibited.

Control Buttons

0 mag

Display Screen Guide

TX/RX LED

Push to Talk

(J) Call Tone

Flash Light

Numbers for Channel.

Numbers for Codes

-Battery Meter

—Channel Power

Indicato

•)) -Talk Confirmation

Q_T -Noise Filtering

ON -On/Off for each

OFF feature

Weathernroof

environments only

Installing the Batteries

1. Turn the radio off.

battery door.

1 Turn the radio off

battery door.

★ Bluetooth

(see menu Options)

Tone (Roger Beep)

Getting Started

This radio is weathernroof to IP-54 standards. It is dust/splashproof from

when the battery cover, headset accessory port, and mini-USB ports are

The charging base and AC adaptor are not waterproof. Do not expose the

charger to rain or snow. Charge the radios only in a dry location. Do not

place wet radios into the charging base. The battery door must be tightly

closed with the screw to maintain the weatherproof seal of the radio.

Each radio can use either 1 NiMH rechargeable battery pack or 3 AA

2. With the back of the radio facing you, make a 1/4 turn to loosen the

3. Remove the NiMH battery pack from the clear plastic bag (do not

4. Insert the NiMH battery pack with the diagram facing you. (The

5. Close the battery cover and tighten the retaining screw on the

Installing the Three AA Alkaline Batteries (Optional Accessory)

and should wrap around the right side of the batteries.

4. Close the battery cover and tighten the retaining screw on the

3. Insert the three AA alkaline batteries with + and - polarity as shown

inside. (The ribbon should be underneath the AA alkaline batteries

around the right side of the pack for easy removal.)

ribbon should be underneath the battery pack and should wrap

retaining screw on the battery door and open the cover.

alkaline batteries and beeps when the batteries are low.

Installing NiMH Rechargeable Battery Pack

disassemble or unwrap the battery pack).

sealed. Open the battery compartment door or headset port cover only

any direction. The radio is resistant to water and rain splashes only

when the radio is dry. Use of a headset accessory should be in dry

Call Tone

Scroll

Emergency Ale

- (Ex) Scan / Monito

------ ((1° (2 × •))

Q_T ON

(b) OFF

188ivõx

♥ −Vibrate

(b) −Dual Scan

Call Tone.

→ Weather Alert

iVOX -Hands-Free Use

VOX -Hands-Free Use

With Accessorie

Keypad Tone

∠ −Scan

– 😭 Menu / Keypad Lock

+) Scroll / Weather

The radio battery icon shows the battery charge level, from full so to empty ____. When the radio has one segment left, the radio chirps periodically or after releasing (FIT) (Low Battery Alert).

Removing the NiMH Battery Pack

retaining screw on the battery door.

- 1. Turn the radio off.
- 2. With the back of the radio facing you, make a 1/4 turn counter clockwise to loosen the retaining screw on the battery door and open the cover.
- 3. Remove the NiMH battery pack by pulling the ribbon attached to the radio
- 4. Close the battery cover and make a 1/4 turn clockwise to tighten the

Removing the Three AA Alkaline Batteries (Optional Accessory)

- 1 Turn the radio off
- 2. With the back of the radio facing you, make a 1/4 turn counter clockwise to loosen the retaining screw on the battery door and open the cover.
- 3. Gently remove each alkaline battery by easing each battery out individually
- 4. Close the battery cover and make a 1/4 turn clockwise to tighten the retaining screw on the battery door.

- · Exercise care when removing NiMH or AA batteries. Do not use sharp or conductive tools to remove either of these batteries.
- Remove the batteries before storing your radio for extended periods of time. Batteries corrode over time and may cause permanent damage to your radio

Using the mini-USB Charging Adaptor

The mini-USB charging adaptor allows you to conveniently charge your NiMH battery pack. This is an alternative to charging your NiMH battery pack in the Battery Charger desk stand using the AC wall adaptor and especially useful when used while traveling

Available mini-USB charging options:

- Vehicle charger 2. Mini-USB computer cable
- If using a computer, the computer must be turned on.

motorolasolutions.com/talkabout or shop.giantintl.com

This and other accessories (sold separately) are available for your radio. For more information, visit our Web site at

- 1. Plug your mini-USB cable or charger into a power source as is appropriate for your accessory
- 2. Plug the cable into the mini-USB port on the side of your radio.
- 3. After the initial charge, an empty battery will be fully charged in 14 hrs. 3. Press m to save the channel setting or to continue set up. (KEBT-1300 mAh NiMH battery pack). 4. The battery icon will scroll as the battery is being charged. The

scrolling icon will stop when the battery is fully charged.

- . When moving between hot and cold temperatures, do not charge the NiMH battery pack until the battery temperature acclimates (usually about 20 minutes)
- If the radio is kept on while charging, the charging time will be extended
- Even though the charger is connected, you may not be able to transmit a message if the battery is completely empty . Allow time for the battery to charge to 1 bar before attempting to transmit a message

Attaching and Removing the Belt Clip

- 1. Attach belt clip to pocket or belt strap.
- 2. Align the belt clip post with the hole in the back of the radio. 3. Gently push until the clip clicks in place.

- 1. Push down on the release tab at the top of the belt clip to release the catch
- 2. Pull the belt clip away from the back of the radio. Using the Desktop Battery Charger (Optional Accessory) (Model 1501)

The battery charger provides drop-in charging convenience for NiMH batteries and can be placed on any flat surface, such as a desk or workbench. Charge the NiMH battery overnight (at least 16 hours) before using it for the first time.

- 1. Follow the steps above to install a NiMH Battery Pack.
- 2. Plug the AC power supply cord into the jack on the desk stand. 3. Plug the AC power supply into a standard wall outlet
- 4. With a radio facing forward, slide it into one of the charging pockets.
- 5. When charging in the battery charger, the battery icon will scroll as the battery is being charged. The scrolling icon will stop when the battery is fully charged.

Turning your Radio On and Off

Turn 🖺 clockwise to turn the radio on and counterclockwise to turn the 2. With the back of the radio facing you, make a 1/4 clockwise turn to loosen the retaining screw on the battery door and open the cover.

- 1. In the ON position, the radio chirps and briefly shows all feature icons available on the radio.
- 2. The display screen then shows the current channel, code and all features that are enabled

Setting the Volume

Press and hold for three seconds, then rotate 1 until you reach a comfortable listening level

- 1. Rotate (1) clockwise to increase the volume.
- 2. Rotate (1) counterclockwise to decrease the volume
- Do not hold the radio close to your ear. If the volume is set to an uncomfortable level, it could hurt your ear.

Talking and Listening

To communicate, all radios in your group must be set to the same channel and Interference Eliminator Code.

- 1. To talk, press and hold [FT]
- 2. When you are finished talking, release [PT] .

For maximum clarity, hold the radio two to three inches away from your mouth and speak directly into the microphone. Do not cover the microphone while talking.

Talk Range

Your radio is designed to maximize performance and improve transmission range. Do not use the radios closer than five feet apart.

the end button when talking. If you know your party is close by, you can conserve your battery's energy by pushing the lower part of the PTT button to use less power. **Monitor Button**

To boost your radio's power up to high power, press the top portion of

Pressing and holding for three seconds allows you to listen to the volume level of the radio when you are not receiving. This allows you to

continuous seconds.

activity on the current channel before you talk. Push to Talk PTT Timeout Timer To prevent accidental transmissions and save battery life, the radio emits a continuous warning tone and stops transmitting if you press (m) for 60

adjust the volume, if necessary. You can also press 🗟 to check for

Menu Options

Selecting the Channel

Your radio has 22 channels. The channel is the frequency the radio uses to transmit. Channels 8-14 are FRS 0.5 watt only and all other channels are GMRS. (See the "Channels and Frequencies" table on overleaf for details.)

- 1. With the radio on, press 🐨 . The current channel will flash. 2. Press + or - and select an unused or quiet channel.
- Note: When the radio is on a 0.5 watt channel, $\, \, \partial \,$ displays. When the radio is on a 1.5 watts channel, "" displays

FRS / GMRS SIMPLEX CHANNELS AND FREQUENCIES					
Channel	FREQ. (MHz)	TYPE	Channel	FREQ. (MHz)	TYPE
1	462.5625	GMRS/FRS	12	467.6625	FRS
2	462.5875	GMRS/FRS	13	467.6875	FRS
3	462.6125	GMRS/FRS	14	467.7125	FRS
4	462.6375	GMRS/FRS	15	462.5500	GMRS
5	462.6625	GMRS/FRS	16	462.5750	GMRS
6	462.6875	GMRS/FRS	17	462.6000	GMRS
7	462.7125	GMRS/FRS	18	462.6250	GMRS
8	467.5625	FRS	19	462.6500	GMRS
9	467.5875	FRS	20	462.6750	GMRS
10	467.6125	FRS	21	462.7000	GMRS
11	467.6375	FRS	22	462.7250	GMRS

Selecting the Interference Eliminator Code

Interference Eliminator Codes help minimize interference by blocking transmissions from unknown sources. Your radio has 121 Interference Eliminator Codes. Codes 1 – 38 are the standard analog codes that appear on other FRS/GMRS radios. Codes 39 - 121 are additional digital codes added for superior interference protection, 0 is the off position, no analog or digital codes are enabled

- 1 Press until the code starts to flash
- 2. Press 🛨 or $\overline{-}$ to select the code.
- 3. Press en to save the code setting or to continue set up. You can set a different code for each channel using this procedure Δn

extended press + or - allows you to scroll through the Interference Code rapidly so you can quickly reach the code you want.

Note: You must set the Interference Eliminator Code to 0 to communicate with radios that do not have Interference Eliminator Codes.

4	77.0	42	031	84	346
5	79.7	43	032	85	351
6	82.5	44	043	86	364
7	85.4	45	047	87	365
8	88.5	46	051	88	371
9	91.5	47	054	89	411
10	94.8	48	065	90	412
11	97.4	49	071	91	413
12	100.0	50	072	92	423
13	103.5	51	073	93	431
14	107.2	52	074	94	432
15	110.9	53	114	95	445
16	114.8	54	115	96	464
17	118.8	55	116	97	465
18	123.0	56	125	98	466
19	127.3	57	131	99	503
20	131.8	58	132	100	506
21	136.5	59	134	101	516
22	141.3	60	143	102	532
23	146.2	61	152	103	546
24	151.4	62	155	104	565
25	156.7	63	156	105	606
26	162.2	64	162	106	612
27	167.9	65	165	107	624
28	173.8	66	172	108	627
29	179.9	67	174	109	631
30	186.2	68	205	110	632
31	192.8	69	223	111	654
32	203.5	70	226	112	662
33	210.7	71	243	113	664
34	218.1	72	244	114	703
35	225.7	73	245	115	712
36	233.6	74	251	116	723
37	241.8	75	261	117	731
38	250.3	76	263	118	732
		77	265	119	734
		78	271	120	743
		79	306	121	754
		80	311		

CODE (Hz) CODE (OCTAL) CODE (OCTAL)

67.0 39 023 81

74.4 41 026 83

71.9

Setting and Transmitting Call Tones Your radio can transmit different call tones to other radios in your group

so you can alert them that you want to talk. Your radio has 20 call tones from which to choose

1. Press three times until the current call tone setting flashes and

- 2. Press (+) or (-) to change and hear the call tone. 3. Press en to set the new call tone or to continue set up.

Interference Eliminator Code as your radio, press 🕗 . Note: Setting the call to 0 disables the call tone feature.

Hands-Free Use Without Accessories (ivox)

You can use the iVOX feature to transmit hands-free without the need for any headset accessories. Once iVOX is turned on, the radio detects your voice and transmits when you speak into the internal microphone.

To transmit your call tone to other radios set to the same channel and

- 1. Press an until ivox appears on the display. The current setting On/Off
- 2. Press 🛨 or 🖃 to select On or Off.
- 3. Press (FT) to set or (Te) to continue set up.

Hands-Free Use With Accessories (vox) You can transmit hands-free more reliably with the use of ontional headset accessories. Once VOX is turned on, the radio detects your voice

and transmits when you speak. Many accessories (sold separately) are available for your radio. For more information, visit our Web site at motorolasolutions.com/talkabout or

1. Turn the radio off and plug the VOX accessory into the accessory port.

shop.giantintl.com.

- 2. Turn the radio on, VOX shows on the display.
- 3. Adjust the volume appropriately by rotating 🚹 . Lower the volume before placing the accessory on your head or in your ear.

4. To turn off, simply remove accessory. Note: There is a short delay between the time you start talking and when the radio transmits. There is a short delay before the transmission is

Setting the Sensitivity Level When in vox Mode Adjusting the radio's sensitivity level helps minimize the possibility of unintended noises triggering a transmission and helps the radio pick up

- 1. Press until VOX and the level setting (1 3) appear on the display. 2. Press (+) or (-) to select the sensitivity level.
- 3. Press (T) to set or (a) to continue set up.

Continued on back

- 3 = High Sensitivity for quiet environments
- 2 = Medium Sensitivity for most environments
- 1 = Low Sensitivity for noisy environments

Note: When you connect a headset, the radio is automatically set to the last chosen sensitivity level.

Q_∓ Noise Filtering

The O_T noise-filtering feature helps to ensure uninterrupted communication with other Motorola radios that have this feature. This feature also filters out unwanted transmissions from other radios. This is useful in places where there is heavy radio traffic. such as amusement parks or ski resorts.

Note: Q_T noise filtering is not available when the radio is scanning.

To turn Q_T noise filtering on or off:

- 1. Press until a displays. The current setting On/Off will flash.
- 2. Press + or to turn noise filtering On or Off.
- 3. Press (**) to confirm your selection or (**) to continue set up.
- To transmit to a radio that has Q_T noise filtering turned on:
- 1. Select the same channel and Interference Eliminator Code as the other radio.
- 2. Press en and speak normally.

Note: For a 30-second period, starting after the last transmission, all transmissions received on the selected channel and code will pass through the Q_T noise filter.

VibraCall™ Alert

VibraCall™ is a vibrating alert that notifies you that your radio is receiving a message. This is useful in noisy environments. When the alert is on, the radio vibrates once every 30 seconds when you receive a message on the channel and code you set

- 1. To turn vibrating alerts on, press 🐨 until 🐧 is displayed. The current setting will flash.
- 2. Press (+) or (-) to change the setting to On/Off.
- 3. Press (T) to set or (T) to continue set up.

You may enable or disable the speaker key tones. You will hear the key tone each time a button is pushed.

- 1. Press until appears. The current setting On/Off will flash. 2. Press either • or • to turn On or Off.
- 3. Press (PT) to confirm or (1) to continue set up.
- Note: When the key tone feature is off the following are not disabled

- Transmit timeout alert tone Call tone
- Low battery alert tone or The transmitted talk confirmation tone

Transmitting a Talk Confirmation Tone

You can set your radio to transmit a unique tone when you finish transmitting. It is like saying "Roger" or "Over" to let others know you are finished talking.

- 1. With the radio on, press wuntil the wappears. The current setting On/Off flashes
- 2. Press + or to turn On or Off.
- 3. Press em to set or to quit menu mode.

Dual Watch Scan

This feature allows you to monitor two channels at the same time.

- 1 Press the (a) button until the Dual Channel Scan icon (a) displays
- 2. Press the 🛨 or 🕒 buttons to select the second channel for Dual Watch
- reception. (if you want to disable the Dual Watch function, set it to 'OFF'). 3. Press 🐨 or the PTT button to confirm the channel selection.

When the Dual Watch feature is activated, the radio will switch sequentially between the primary and the Dual Watch channels The active channel will display for five (5) seconds after any activity has

ended on the dual channel. You may talk on the Dual Watch channel during this period.

BLUETOOTH® Pairing

The MU series BLUETOOTH® radio works with any qualified BLUETOOTH® headsets from BLUETOOTH® SIG. Inc. and with the Talkabout® Wireless BLUETOOTH® PTT POD - 1693.

Note: To avoid paring to the wrong device, please switch off all other Bluetooth devices before pairing process. 1. With the radio on, briefly press until * appears on the LCD. The

- current setting On/Off will flash
- 2. Press either the + or the to select On.
- 3. Press the PTT button to confirm the selection. The BLUETOOTH® of the radio is now in standby (connectable) mode

Pairing any BT headset with the MU350 Series Radio

- 1. With the MU350 BLUETOOTH® enabled, press and hold the button for about three seconds to enter pairing mode. A tone will sound and the BLUETHOOTH®blue LED indicator on the radio will flash quickly.
- 2. Follow the BLUETOOTH® headset manufacturer's instruction to enable its BLUETOOTH® function and entry to paring mode.

- 3. Successful pairing will be indicated on the MU350 radio by a tone and a brief flashing of the BLUETOOTH®LED indicator to confirm
- 4. With the MU350 BLUET00TH® enabled, press and hold the \bigcirc button for about three seconds to enter pairing mode. A tone will sound and the BLUETOOTH® blue LED indicator on the radio will

Pairing the PTT Pod - 1693 with the MU350 Series Radio

- 1. Enable the MU350 Series Radio's Bluetooth functionality (see above)
- 2 Ensure the PTT Pod is off
- 3. Press and hold the power on/off button until the PTT Pod LED indicator light flashes blue and red alternatively
- 4. With the MU350 Series Radio BLUETOOTH®enabled, press and hold the - button for about three seconds to enter pairing mode. A tone will sound and the BLUETOOTH® blue LED indicator on the radio will
- 5. Successful pairing will be indicated by a tone and brief flashing of the BLUETOOTH®LED indicator to confirm entry to connected mode.
- 6. If pairing was successful, the BLUETOOTH®LED indicator of the radio will flash blue at 5 second intervals.
- 7. If pairing fails, turn the PTT Pod and the MU350 Series Radio off and repeat the above process.

After successful pairing, you can talk and listen via the paired BLUETOOTH® headset and/or use the PTT Pod to activate the PTT function on the MU350 series radio

Note: You must press and hold $\stackrel{\text{(pt)}}{=}$ on the radio to transmit when only a headset is paired (to enable the wireless PTT function, the MU350 series radio also needs to be paired with the Bluetooth PTT POD model 1693). To turn off the BLUETOOTH® function:

- 1. With the radio on, short press 🗑 until 🔻 appears. The current setting On/Off will flash
- 2. Press + or to select Off
- 3. Press m to set or to continue set up. The BLUETOOTH® LED indicator will stop flashing.

Note: The PTT Pod is an optional accessory which is sold separately

Special Features

Emergency Alert Mode

The Emergency Alert feature can be used to signal members in your group if you need urgent help. The MU Series radios will operate in an automatic "hands-free" emergency control mode for a total of 30 seconds after activating the Emergency Alert. The MU Series radios in your group will automatically advance the speaker volume to the naximum setting and sound a warbling alert tone for 8 seconds. The alert tone is emitted from your own radio speaker and the receiving radios in your group. After the 8 second alert, any spoken words or incidental sounds at your end will be transmitted to the group for 22 seconds. For the 30 second duration of Emergency Alert mode, the MU Series radio controls and buttons will be locked to maximize reception of the emergency message.

- 1. Press and hold the Emergency Alert button (1) for three seconds.
- 2. Release the button after the LED Indicator glows red and the alert tone begins to sound. There is no need to continue to hold the Emergency Alert button or use PTT for your message to be transmitted.
- 3. After the alert tone ends you may speak into the microphone. Your voice or incidental sounds will be transmitted. The LED indicator will continue to glow for the duration of the 22 second period.
- 4. After 30 seconds your radio speaker will emit a Talk Confirmation Tone and the LED Indicator will extinguish. Operation then returns to normal two-way mode.

Note: All Motorola Talkabout EM, MJ, MR, MT and MU Series radios are fully compatible with the Emergency Alert feature. Radios other than EM, MJ, MR, MT and MU Series can receive the emergency alert signal, but will not respond with adjusted volume settings, locked controls, or a warbling alert tone. Users of other radio models set to the same channel and Interference Eliminator Code will hear a steady tone for eight seconds followed by the voice transmission for 22 seconds

Warning: The Emergency Alert feature should only be used in the event of an actual emergency. Motorola is not responsible if there is no response to the emergency alert from the receiving group.

Press and hold the flashlight button to turn and keep the light on. The switch functions as a momentary control for the light

Note: Turn off the flashlight when not in use to conserve battery power.

To avoid accidentally changing your radio settings:

- Press and hold until a displays.
- 2. When in lock mode, you can turn the radio on and off, adjust the volume, receive, transmit, send a call tone, and monitor channels. All other functions are locked

To unlock the radio, press and hold until a is no longer displayed.

Use scan to search the 22 channels for transmissions from unknown parties, to find someone in your group who has accidentally changed channels, or to quickly find unused channels for your own use

There is a priority feature and 2 modes of scanning (basic and advanced) to make your search more effective. The basic scan mode uses the channel and code combinations for each of the 22 channels as you have set them (or with the default code value of 1). The "Advanced Scan" mode will scan all channels for any and all codes, detect any code in use, and use that code value temporarily for that channel.

Priority is given to the "home channel" that is the channel (and Interference Fliminator Code) your radio is set to when you start the scan This means the initial channel (and code setting) is scanned more often than the other 21 channels, and your radio will respond quickly to any activity occurring on the home channel as a priority.

To start Scanning:

- 1. Briefly press the ♣ key. The scan ≠ will appear in the display, and the radio will begin to scroll through the channel and code combi
- 2. When the radio detects channel activity matching the channel and code combination, it stops scrolling and you can hear the transmission.
- 3. To respond and talk to the person transmitting, press (m) within five seconds after the end of the transmission.
- . The radio will resume scrolling through the channels five seconds after the end of any received activity.
- 5. To stop scanning, briefly press the key.
- To start Advanced Scanning:
- Set the Interference Eliminator Code to "zero" or OFF.
- 2. Briefly press the key. The scan ≠ will appear in the display, and the radio will begin to scroll through the channels. No Interference Eliminator Codes will filter what is heard.
- 3 When the radio detects channel activity with ANY code (or NO code) it stops scrolling and you can hear the transmission. Any Interference Eliminator Code that may be in use by that party will be detected and displayed.
- seconds of the end of the transmission. The radio will transmit using the newly detected Interference Fliminator Code 5. The radio will resume scrolling through the channels five seconds

To respond and talk to the person transmitting, press (***) within five

after the end of any received activity. 6. To stop scanning, briefly press the key.

Scanning Notes:

- . If you press (while the radio is scrolling through inactive channels, the transmission will be on the "home channel". Scanning will resume five seconds after the end of your transmission. You may press the lakey to stop scanning at any time.
- 2. If the radio stops on an undesired transmission, you may immediately resume the scan by briefly pressing + or -
- 3. If the radio repeatedly stops on an undesired transmission, you may temporarily remove that channel from the scan list by pressing and holding \odot or \bigcirc for three seconds. You may remove more than one channel in this way.
- To restore the removed channel(s) to the scan list, turn the radio off and then back on, or exit and re-enter the scanning mode by pressing 🟝 .
- 5. You cannot remove the home channel from the scan list.
- 6 In Advanced Scan, the detected code will only be used for one transmission. You must note the code, exit scan, and set that detected code on that channel to permanently use the detected code

Weather Receiver

Your radio can tune in to broadcasts by the United States National Oceania and Atmospheric Administration (NOAA) Weather Radio You can listen to a weather channel (see "Weather Channels and Frequencies" table for details) or set your radio to alert you to emergency weather broadcasts that interrupt routine broadcasts. When you listen to a weather channel, you cannot use your radio in scan mode or for two-way

NOAA has transmitters located throughout the United States. These transmitters broadcast watches, forecasts, and other information 24 hours

Note: NOAA weather radio stations are assigned to cover specific areas and service may be limited. Please check with your local weather office for frequency and details, or visit www.weather.gov/nwr in the US to view the appropriate transmitter for your area.

endorsement by NOAA's National Weather Service

Turning Weather Channel Reception On and Off To turn weather reception on, press + and hold for 3 seconds.

The use of the NOAA logo does not provide an endorsement or implied

2. To turn off, press 🛨 or turn the radio off and then back on.

Setting the Weather Channel

- Your radio receives weather frequencies
- 1. After turning weather reception on, press 🖫 . The current channel flashes
- 2. Press 🛨 or 🗨 to select the appropriate channel with good reception in your area.
- 3. Press (FT) to save the weather channel setting.

Setting the Weather Alert

Your radio can be set to respond to NOAA Weather Radio emergency messages. A special alarm tone sounds an alert and turns on the weather receiver to give you immediate weather and emergency

1. After turning weather reception on, press (**) twice, On/Off displays.

- 2. Press 🛨 or 😑 to select On/Off. If you activate Weather Alert and return to two-way mode, 🥽 will display.
- 3 Press (PIT) to save the Weather Alert setting
- 4. Press (+) to return to two-way mode.

As with two-way radio reception, weather channel reception depends on how close you are to a transmitter and whether you are indoors or outdoors. Because weather channels are transmitted without codes, they may contain static or noise. Weather Alert will not function while actively transmitting or receiving in two-way mode

Scanning for Weather Channel

The radio can scan for an active NOAA transmission automatically.

- 1. After turning weather reception on, briefly press the key.
- 2. The scan icon $oldsymbol{\mathbf{z}}$ will appear in the display, and the channel will scroll through the NOAA channels 1-7.
- 3. When the radio detects channel activity, it stops scanning and you can hear the transmission
- 4. You may resume the scan by briefly pressing (+) or (-).
- 5. To stop scanning, briefly press the ♣ key. The scan icon ∠ will

Weather Channels and Frequencies

Weather Channel	Frequency	Weather Channel	Frequency
WX1	162.550 MHz	WX7	162.525 MHz
WX2	162.400 MHz	WX8	161.650 MHz
WX3	162.475 MHz	WX9	161.775 MHz
WX4	162.425 MHz	WX10	161.750 MHz
WX5	162.450 MHz	WX11	162.000 MHz
WX6	162.500 MHz		

Patent and Copyright Information Manufactured, distributed or sold by Giant International Ltd., official

licensee for this product. MOTOROLA, MOTOROLA SOLUTIONS and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners. ©2013 Motorola Solutions, Inc. All rights reserved.

Warranty

Consumer Two-Way Radio Products and Accessories purchased in the United States

What Does this Warranty Cover?

Subject to the exclusions contained to the right, Giant International Ltd. warrants the Motorola branded consumer two-way radios that operate via Family Radio Service or General Mobile Radio Service that it manufactures ("Products"), the Motorola branded or certified accessories sold for use with these Products that it manufactures ("Accessories") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive. remedy, and applies as follows to new Motorola branded Products. and Accessories manufactured by Giant International Ltd., and purchased by consumers in the United States, which are accompanied by this written warranty:

Who is covered?

This warranty extends only to the first consumer purchaser, and is not transferable. It covers use by consumers for recreational use only.

What will GIANT INTERNATIONAL LTD. do? GIANT INTERNATIONAL LTD., at its option, will at no charge repair,

Products Covered

Products and Accessories as

otherwise provided for below.

Consumer Two-Way Radio

Products and Accessories

that are Repaired or

defined above, unless

Accessories.

Replaced.

replace or refund the purchase price of any Products or Accessories that does not conform to this warranty. We may use functionally equivalent reconditioned/ refurbished/ pre-owned or new Products, Accessories or parts.

Length of Coverage

date of purchase by the first

consumer purchaser of the

The balance of the original

warranty or for ninety (90)

days from the date returned

to the consumer, whichever

product.

is longer.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. OTHERWISE THE REPAIR REPLACEMENT OR REFLIND AS PROVIDED LINDER THIS EXPRESS. LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER AND IS PROVIDED IN LIFT OF ALL OTHER WARRANTIES, EXPRESS OF IMPLIED. IN NO EVENT SHALL MOTOROLA SOLUTIONS, INC. OR GIANT INTERNATIONAL LTD. BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Exclusions

One (1) year from the date of	Normal Wear and Tear. Periodic maintenance, repair and
purchase by the first consumer	replacement of parts due to normal wear and tear are excluded
purchaser of the product unless	from coverage.
otherwise provided for below.	
•	Batteries. Only batteries whose fully charged capacity falls below
1. Ninety (90) days from the	80% of their rated capacity and batteries that leak are covered by

this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product esulting from misuse: (b) contact with liquid, water, rain, extreme numidity, heavy perspiration, when the battery door or accessory port seals are not closed, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions or (d) other acts which are not the fault of Motorola Solutions. Inc. or Giant International Ltd., are excluded from coverage

Use of Non-Motorola branded Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products or Accessories or other peripheral equipment are excluded from coverage. <u>Unauthorized Service or Modification.</u> Defects or damages

authorized service centers, are excluded from coverage Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated: (b) broken seals or that show evidence of tampering: (c) mismatched hoard serial numbers: or (d) nonconforming or non-Motorola

maintenance, alteration, or modification in any way by someone other than Motorola Solutions, Inc, Giant International Ltd. or its

resulting from service, testing, adjustment, installation,

Communication Services. Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories is excluded from coverage.

branded housings, or parts, are excluded from coverage.

How to Obtain Warranty Service or Other Information? To obtain service or information, please call:

USA Two-Way Radios 1-800-638-5119 support@giantintl.com

For Accessories, please call the telephone number designated above for the product with which they are used.

You will receive instructions on how to ship the Products or Accessories at your expense, to a GIANT INTERNATIONAL LTD. Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase: (b) a written description of the problem: (c) the name of your service provider, if applicable: (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

MU Series